

**Kit 1: Standard**  
(Bass: Fingered Bass 1)

Drum A	CY1 crash cymbal 1	1	CY2 crash cymbal 2	2	CY12 ride bell cymbal 2	3	CY9 ride cymbal 2	4
	PC22 casaba		CY7 chinese cymbal		PC20 maracas		PC17 vibraslap	
		CRASH 1	CRASH 2		BELL		RIDE	
Drum A	TM1 studio tom 1 soft	5	TM1 studio tom 1 soft	6	TM1 studio tom 1 soft	7	TM3 studio tom 2 soft	8
	PC25 agogo		PC25 agogo		PC18 guiro short		PC19 guiro long	
		TOM 1	TOM 2		TOM 3		TOM 4	
Drum A	STK3 natural cross stick	9	SN1 medium snare soft	10	PC1 cowbell	11	HH3 pedal closed hi-hat	12
	PC7 bongo high		PC8 bongo low		PC14 timbale low		PC13 timbale high	
		CROSS STICK	CLAP		COWBELL		PEDAL HH	
Drum A	KC4 dry medium kick	13	SN2 medium snare rim shot	14	HH1 pure closed hi-hat	15	HH2 pure open hi-hat	16
	PC2 tambourine		PC9 conga high mute		PC11 conga high open		PC12 conga low open	
		KICK	SNARE		CLOSED HH		OPEN HH	