

<b>M-30 ( Record )</b>	<b>Function</b>	<b>34</b>	<b>Preamp</b>
Buss outs 1 - 4	Record	Input 1 - 4	
Line in 5-6	Record		Record Out
Input Selector 5 & 6 set to Line	Record		
Input strip 6 Assign Button 3 down	Record		
Input strip 5 Assign Button 1 down	Record		
Monitor knob 1 (lower) fully left	Record		
Monitor knob 3 (lower) fully Right	Record		
Monitor out	Monitor / Play		Tape in

Recording Note:  
 Input, Synch & Repr buttons on 34  
 Input down - You monitor what is going into the 34  
 Synch down - you monitor what is going onto tape  
 Repr down - you monitor what has recorded on tape

<b>M-30 ( Playback )</b>	<b>Function</b>	<b>34</b>	<b>Preamp</b>
Tape In 1 - 4	Playback	Output 1 - 4	
Input Selector 1 & 3 set to Tape for Remix	Play	Synch or Repr button down	
Input strip 1 Assign Button 1 down	Play		
Input strip 3 Assign Button 3 down	Play		
Monitor knob 1 (lower) fully left	Play		
Monitor knob 3 (lower) fully Right	Play		
Monitor out	Monitor / Play		Tape in

Playback Note:  
 Synch & Repr buttons on 34  
 Synch down - you monitor what has recorded on tape  
 Repr down - you monitor what has recorded on tape