

M-30 (Playback Submix)**Function****34****Preamp**

Tape In 1 - 4

Playback

Output 1 - 4

Input Selector 1 & 3 set to Line

Submix 1 & 3 Set to Tape (This bypasses input strips 1 & 3)

Synch or Repro button down

Submix knob 1 (lower) fully left

Submix knob 3 (lower) fully Right

Submix Knob 1 & 3 (Upper) level as required

Submix Master knob Output level to preamp

Meter Switch set to Submix

Submix out

Tape in

Playback Note:

Synch down - you monitor what has recorded on tape

Synch & Repro buttons on 34

Repro down - you monitor what has recorded on tape