

TimeLine Microlynx Transport Port Pinout

copied from manual, table Ch.7-1, pg. 7-4

by Bill Bainbridge (brainditch)

(Indexed by pin number)

1. Ground
2. Transport Ground Sense
3. Ground
4. Assemble
5. Fast Forward
6. Rewind
7. Mute
8. Pull-up common
9. Record Tally
10. Tach
11. +5V
12. Servo relay B, normally closed contact
13. Rehearse
14. Video Track Enable (INS)
15. Ground
16. Ground
17. Play Tally
18. Audio Track Enable (A2)
19. RS422, TX-

20. RS422, TX+
21. RS422, RX-
22. RS422, RX+
23. Record Exit
24. Search Enable
25. Aux In
26. Search Control Voltage
27. Capstan Frequency
28. Tape Direction
29. Servo Relay B, Normally Open Contact
30. Capstan Control Voltage
31. Record In
32. Servo relay B Common
33. Audio Track Enable (A1)
34. Servo Relay A Common
35. Lifter Enable, In/Out
36. Command Common
37. +12V
38. -12V
39. Stop
40. Play