





# Table of Contents

---

<b>Chapter 1 Introduction</b> .....	<b>1-1</b>
What is the Micro Lynx?.....	1-1
System Components.....	1-2
Options .....	1-2
System Configuration.....	1-3
Keyboard Controller.....	1-3
System Unit.....	1-3
Features .....	1-4
Micro Lynx Keyboard Controller (KBD).....	1-4
Micro Lynx System Unit (SU) .....	1-4
Specifications .....	1-6
Keyboard .....	1-6
System Unit.....	1-6
Time Code Generator .....	1-6
Synchronizer.....	1-6
Transports .....	1-7
Time Code Reader .....	1-7
Aux Inputs.....	1-7
Aux Outputs .....	1-7
Video Input.....	1-7
Video Output .....	1-7
Serial In/Out.....	1-7
Power Supply Unit.....	1-8
Physical .....	1-8
Options .....	1-8
Cable Requirements.....	1-9
<b>Chapter 2 Applications</b> .....	<b>2-1</b>
Introduction .....	2-1
Related TimeLine Products .....	2-1
Third Machine Expansion Card (M3).....	2-1
Digital Audio Clock Generator Card (ACG) .....	2-1
Video Sync Generator Card (VSG) .....	2-2
VITC Reader Card (VITC) .....	2-2
Basic Micro Lynx .....	2-3

## Table of Contents

---

Micro Lynx with a VTR .....	2-4
Micro Lynx with MIDI.....	2-5
Micro Lynx with Third Machine Card Installed.....	2-6
Micro Lynx with a Digital Audio Workstation .....	2-7
Micro Lynx with the Studio System.....	2-8
<b>Chapter 3 Installation.....</b>	<b>3-1</b>
Introduction .....	3-1
Hardware Supplied.....	3-1
System Setup Planning .....	3-1
Power.....	3-2
Fuses .....	3-3
Placement.....	3-3
Mount the System Unit (SU).....	3-3
Rack Mount Procedure .....	3-3
Cabling.....	3-4
Connect the Transports and the System Unit.....	3-5
Connect the Keyboard Controller Cables.....	3-7
Connect the AUX Input.....	3-8
Quick Test and Initialization Procedure.....	3-9
Quick Check Troubleshooting .....	3-13
<b>Chapter 4 Getting Started.....</b>	<b>4-1</b>
Introduction .....	4-1
Turn On and Initialization.....	4-1
Set the System Reference.....	4-5
Generate Time Code .....	4-7
Capture and Locate .....	4-9
Make a Group .....	4-10
Locking in a Group .....	4-11
Set an Offset .....	4-12
Trim an Offset .....	4-16
Change the Master Machine .....	4-17
Do an Edit.....	4-18
Reset the System .....	4-21
CLR.....	4-21
CLR + SYS .....	4-21

CLR + SETUP .....	4-21
CLR + TRAN .....	4-22
Customize the Micro Lynx Setup .....	4-23
Setup .....	4-24
<b>Chapter 5 Troubleshooting.....</b>	<b>5-1</b>
Introduction .....	5-1
System Error Messages .....	5-1
Self Test Messages.....	5-4
Error Messages .....	5-5
Warnings .....	5-6
Prompts .....	5-9
<b>Chapter 6 Operational Features .....</b>	<b>6-1</b>
Introduction .....	6-1
SMPTE Time Code Synchronization.....	6-2
Selecting Which Time Code Standard is Right for Your Application.....	6-2
SMPTE Time Code in the Audio-only Studio.....	6-3
Striping the Tape .....	6-4
SMPTE Time Code in the Integrated Video/Audio Production Studio.....	6-5
Recovering from Bad Time Code and Time Code Dropouts.....	6-6
Jam Sync Functions.....	6-8
Playback Features .....	6-8
Solo Mode - Single Machine Control Functions .....	6-8
Using Cue Points .....	6-9
Setting the Cue Register.....	6-9
Using the Cue Register .....	6-9
Group Mode - Multiple Machine Control .....	6-10
Create a Group.....	6-10
Changing the Master Machine .....	6-11
Resetting the Group.....	6-11
Machine Offsets .....	6-12
Setting the Offsets .....	6-12
Machine Control.....	6-12
Adjusting the PreRoll Time .....	6-13
Adjusting Postroll Time .....	6-13
How To Edit Loop a Group of Machines .....	6-13
Recording Functions .....	6-14
Using an Auxiliary Footswitch for Punch-In/Out Control.....	6-14

## Table of Contents

---

Setting Record Ready Options.....	6-14
Keyboard Operations.....	6-15
Using the Jog Wheel for Trim Operations .....	6-15
Using the Memory Registers .....	6-15
Storing Numbers in the Memory Registers .....	6-16
Recalling Memory Register Contents.....	6-16
Programming Macros.....	6-17
Deleting a Macro.....	6-18
Using the Preprogrammed Macros .....	6-18
Programming Your Own Macros.....	6-18
Program Macro: 0 - - 4 5 6 7 - -.....	6-19
Setting Variable Speed Playback .....	6-19
Code Only Master Operation .....	6-20
Selecting the System Reference .....	6-20
Setting the Master Machine Type.....	6-20
Transport Control .....	6-21
<b>Chapter 7 System Unit.....</b>	<b>7-1</b>
Introduction .....	7-1
Front Panel Indicators and Switches.....	7-2
OPTIONS .....	7-2
MIDI.....	7-2
EXTERNAL COMPUTER .....	7-2
KEYBOARD.....	7-2
SYSTEM.....	7-3
POWER .....	7-3
Video Reference .....	7-3
Transport Connectors.....	7-4
Time Code Readers and Generator .....	7-5
MIDI.....	7-6
Computer .....	7-7
System Tally, Aux In, Aux Out .....	7-9
Third Machine Interface.....	7-11
Audio Clock Generator .....	7-12
VITC.....	7-13
Power.....	7-13
<b>Chapter 8 Keyboard Controller .....</b>	<b>8-1</b>
Introduction .....	8-1

Display .....	8-4
Normal Operating Display.....	8-6
Calculator Display.....	8-7
Register Contents.....	8-8
Setup Display .....	8-9
Prompt & Error Display .....	8-10
Transport Controls.....	8-11
Jog/Shuttle .....	8-16
Jog/Shuttle Wheel .....	8-16
TRIM/LAST .....	8-16
JOG/NEXT .....	8-17
SHTL/ENTR.....	8-17
Device Select Keys .....	8-18
SETUP.....	8-19
Group Select Keys.....	8-28
A-C, TCG, MIDI .....	8-28
Solo Mode .....	8-28
Group Mode .....	8-29
LOCK LED .....	8-29
BUSY LED .....	8-29
REC LED.....	8-29
TCG.....	8-31
MIDI .....	8-32
GRP (GROUP).....	8-36
SOLO .....	8-36
LOOP .....	8-37
RDY .....	8-37
TRKS .....	8-37
Calculator Keys.....	8-41
00 .....	8-41
CLR.....	8-41
0 TIME/VID.....	8-43
1 PRE/A1 .....	8-44
2 POST/A2 .....	8-44
3 REF/A3 .....	8-45
4 SYNC/P/A4 .....	8-45
5 OFST/CUE.....	8-47
6 ERR/TC.....	8-49
7 IN.....	8-50
8 OUT .....	8-50

## Table of Contents

---

9 DUR/ASM.....	8-50
Auxiliary Function Keys.....	8-52
RCL.....	8-52
STO.....	8-53
MACRO .....	8-54
CAPT .....	8-55
= (equal) .....	8-56
+ (plus).....	8-56
- (minus) .....	8-57
SUBFR .....	8-59
Status Indicators .....	8-60
System.....	8-60
Digital Audio Clock Generator LEDs.....	8-62
<b>Chapter 9 Advanced Features.....</b>	<b>9-1</b>
Using AVID AudioVision with the Micro Lynx .....	9-1
To Control One Transport Device with the Micro Lynx .....	9-2
To Control Multiple Transport Devices with the Micro Lynx .....	9-3
To Slave AudioVision from an External Deck Connected to the Micro Lynx .....	9-3
Using Pro Tools with the Micro Lynx .....	9-4
Introduction .....	9-4
System Set Up And Configuration: Pro Tools as Slave .....	9-5
VITC Option Card Setup and Configuration for Pro Tools .....	9-8
System Setup And Configuration: Pro Tools as Master .....	9-9
Advanced MIDI Features .....	9-11
General Features .....	9-11
MIDI Setup Menu .....	9-11
Description Of Settings.....	9-12
Other Setting Descriptions.....	9-14
Using Mediasound with the Micro Lynx.....	9-15
Introduction .....	9-15
Micro Lynx Options Necessary for Video Sync .....	9-15
Using Mediasound with the Micro Lynx.....	9-16
Micro Lynx to Computer Connections.....	9-18
Micro Lynx to VTR Connections (Typical) .....	9-19
Micro Lynx Setup.....	9-20
Audio Clock Generator Setup.....	9-20
MIDI Time Code Setup.....	9-21
MIDI Data Source Setup .....	9-22
System Reference Setup .....	9-22

Time Code Generator Setup .....	9-23
Micro Lynx Operation.....	9-24
Controlling Mediasound with the Micro Lynx .....	9-24
Controlling One Transport Device with the Micro Lynx .....	9-25
<b>Chapter 10 Option Cards.....</b>	<b>10-1</b>
Video Sync Generator (VSG) Card .....	10-2
Installation Procedure .....	10-2
M3 Option Card .....	10-4
Transport Options.....	10-4
M3 Card Initialization Procedure.....	10-7
Installation Instructions .....	10-8
Digital Audio Clock Generator Card (ACG).....	10-12
Speed Reference .....	10-12
The ACG Solution .....	10-12
ACG-1 Features.....	10-13
ACG-2 Features.....	10-14
Operation.....	10-15
Setup Options.....	10-16
Digital Audio Clock Generator LEDs .....	10-17
Audio Clock Generator Outputs .....	10-19
ACG Card Setup.....	10-20
Error Conditions .....	10-21
Installation Instructions .....	10-21
VITC Reader Card .....	10-27
Features.....	10-27
Introduction.....	10-27
Installation Instructions .....	10-28
Operation Instructions.....	10-31
[F3] VITC Options.....	10-32
VITC Display and Status.....	10-32
<b>Appendix A .....</b>	<b>A-1</b>
Introduction .....	A-1
SMPTE Made Simple.....	A-1
Introduction.....	A-3
Why SMPTE? .....	A-3
What Can You Do with SMPTE?.....	A-3
Synchronizing Multiple Audio Machines .....	A-4
Locking to Picture .....	A-5

## Table of Contents

---

Mix Automation and More.....	A-5
Complete Systems.....	A-6
How Does SMPTE Do It?.....	A-7
What You Can Do with a Speed Reference.....	A-7
SMPTE: What You Can Do with a Speed and Position Reference.....	A-8
Anatomy of a SMPTE Frame.....	A-9
Time Code Formats.....	A-10
National Television Standards Committee (NTSC).....	A-10
Phase Alternate Line (PAL).....	A-10
Drop Frame (DF).....	A-10
Film.....	A-11
Different Frame Rate Formats.....	A-11
VITC.....	A-12
SMPTE, MIDI and MTC.....	A-13
Using SMPTE.....	A-14
Things To Know About Generating Time Code.....	A-14
Reshaping Time Code.....	A-15
Regeneration or Jam Sync.....	A-16
About Time Code Readers.....	A-16
Synchronizer Essentials.....	A-16
Phase or Sync Lock.....	A-17
Advanced Applications.....	A-17
Video Editing.....	A-17
Audio-For-Video.....	A-18
The Modern Electronic Recording Studio.....	A-20
SMPTE and the Digital Audio Workstation.....	A-21
The SMPTE Future.....	A-22
Setup Quick Reference.....	A-23
Cable Reference Guide.....	A-27
Key and Key Combination Identification Numbers.....	A-31
Glossary.....	A33
<b>Index.....</b>	<b>Index-1</b>
List of Figures.....	xv
List of Tables.....	xvii

## List of Figures

Figure Chapter 1 -1. Micro Lynx.....	1-1
Figure Chapter 1 -2. System Block Diagram.....	1-2
Figure Chapter 2 -1. Basic Micro Lynx.....	2-3
Figure Chapter 2 -2. Micro Lynx with a VTR.....	2-4
Figure Chapter 2 -3. Micro Lynx with MIDI .....	2-5
Figure Chapter 2 -4. Micro Lynx with Third Machine Card Installed .....	2-6
Figure Chapter 2 -5. Micro Lynx with a Digital Audio Workstation.....	2-7
Figure Chapter 2 -6. Micro Lynx with the Studio System .....	2-8
Figure Chapter 3 -1. Power Supply Connection .....	3-2
Figure Chapter 3 -2. Connect the Transports to the System Unit.....	3-5
Figure Chapter 3 -3. Micro Lynx System Unit to Keyboard Controller Connection.....	3-7
Figure Chapter 3 -4. Micro Lynx Keyboard Controller to Foot Switch.....	3-8
Figure Chapter 7 -1. System Unit.....	7-1
Figure Chapter 7 -2. Front Panel Indicators and Switches .....	7-2
Figure Chapter 7 -3. Video Reference .....	7-3
Figure Chapter 7 -4. Transport Connectors.....	7-4
Figure Chapter 7 -5. Time Code Readers and Generator.....	7-5
Figure Chapter 7 -6. MIDI .....	7-6
Figure Chapter 7 -7. External Control Interface.....	7-7
Figure Chapter 7 -8. System Tally and Aux Jacks.....	7-9
Figure Chapter 7 -9. Third Machine Interface .....	7-11
Figure Chapter 7 -10. Audio Clock Generator.....	7-12
Figure Chapter 7 -11. VITC Interface.....	7-13
Figure Chapter 7 -12. Power .....	7-13
Figure Chapter 8 -1. Front Panel.....	8-1
Figure Chapter 8 -2. Keyboard Key Locator.....	8-2
Figure Chapter 8 -3. Display.....	8-4
Figure Chapter 8 -4. Motion Control Keys .....	8-11
Figure Chapter 8 -5. Jog/Shuttle.....	8-16
Figure Chapter 8 -6. Device Select Keys.....	8-18
Figure Chapter 8 -7. Group Select Keys .....	8-28
Figure Chapter 8 -8. Calculator Keys .....	8-39
Figure Chapter 8 -9. Auxiliary Function Keys .....	8-50

## Table of Contents

---

Figure Chapter 8 -10. Status Indicator .....	8-58
Figure Chapter 9 -1. MIDI Routing .....	9-13
Figure Chapter 9 -2. Micro Lynx with an SGI Workstation .....	9-17
Figure Chapter 9 -3. Micro Lynx to SGI Workstation Connections.....	9-18
Figure Chapter 9 -4. Micro Lynx to VTR Connections.....	9-19
Figure Chapter 10 -1. Video Sync Generator Card .....	10-3
Figure Chapter 10 -2. Remove the Support Bracket.....	10-8
Figure Chapter 10 -3. Install the Option Card Bracket.....	10-9
Figure Chapter 10 -4. Installation of M3 Card.....	10-9
Figure Chapter 10 -5. Installation of M3 Card.....	10-10
Figure Chapter 10 -6. ACG Block Diagram.....	10-13
Figure Chapter 10 -7. Audio Clock Generator Inputs/Outputs .....	10-19
Figure Chapter 10 -8. Remove Support Bracket .....	10-22
Figure Chapter 10 -9. Install the Option Card Bracket.....	10-22
Figure Chapter 10 -10. Option Cable Installation .....	10-23
Figure Chapter 10 -11. Installation of the ACG Card.....	10-24
Figure Chapter 10 -12. Relocation of “L” Bracket .....	10-25
Figure Chapter 10 -13. Install the ACG Option Card Bracket.....	10-25
Figure Chapter 10 -14. Install the ACG Card .....	10-26
Figure Chapter 10 -15. Remove the Support Bracket.....	10-28
Figure Chapter 10 -16. Install the Option Card Bracket.....	10-29
Figure Chapter 10 -17. Securing the VITC Card .....	10-29
Figure Chapter 10 -18. Securing the VITC Card .....	10-31
Figure Appendix A-1. Basic SMPTE Time Code Setup.....	A-4
Figure Appendix A-2. Synchronize to Video.....	A-5
Figure Appendix A-3. MIDI Sequencer and Time Code.....	A-6
Figure Appendix A-4. Complete Studio System .....	A-6
Figure Appendix A-5. Two Sine Wave Signals in Phase.....	A-8
Figure Appendix A-6. Time Code Address.....	A-9
Figure Appendix A-7. Video Tape and VITC Time Code.....	A-12
Figure Appendix A-8. Reshaping Time Code.....	A-15
Figure Appendix A-9. Jam Sync .....	A-16
Figure Appendix A-10. Automated Mixing System.....	A-19
Figure Appendix A-11. The “Modern” Electronic Studio .....	A-20
Figure Appendix A-12. Micro Lynx with a Digital Audio Workstation .....	A-21

## List of Tables

Table Chapter 1 -1. Cable Requirements.....	1-9
Table Chapter 3 -1. Cable Requirements.....	3-4
Table Chapter 3 -2. Cable Check List .....	3-6
Table Chapter 3 -3. AUX Connector Pin Description.....	3-8
Table Chapter 3 -4. Troubleshooting the System Unit.....	3-13
Table Chapter 3 -5. Troubleshooting the System Unit communications with the Keyboard Controller.....	3-13
Table Chapter 3 -6. Troubleshooting the Micro Lynx communications with the machines..	3-13
Table Chapter 4 -1. TCG Options Menu .....	4-5
Table Chapter 4 -2. Micro Lynx Setup Menu .....	4-24
Table Chapter 4 -3. Micro Lynx Setup Selections .....	4-25
Table Chapter 7 -1. Transport Connector Pin Description .....	7-4
Table Chapter 7 -2. RDR 1 Time Code Connector Pin Description.....	7-5
Table Chapter 7 -3. RDR 2 Time Code Connector Pin Description.....	7-5
Table Chapter 7 -4. Time Code OUT Connector Pin Description .....	7-5
Table Chapter 7 -5. MIDI IN Connector Pin Description.....	7-6
Table Chapter 7 -6. MIDI OUT Connector Pin Description.....	7-6
Table Chapter 7 -7. MIDI THRU/OUT Connector Pin Description .....	7-6
Table Chapter 7 -8. I/F Connector Pin Description .....	7-7
Table Chapter 7 -9. I/F Connector Pin Description .....	7-7
Table Chapter 7 -10. RS232/422 Connector Pin Description .....	7-8
Table Chapter 7 -11. Keyboard Connector Pin Description .....	7-8
Table Chapter 7 -12. System Tally Connector Pin Description .....	7-9
Table Chapter 7 -13. Aux In Connector Pin Description.....	7-9
Table Chapter 7 -14. Aux Out Connector Pin Description.....	7-10
Table Chapter 7 -15. Transport 3 Connector Pin Description .....	7-11
Table Chapter 7 -16. AES/EBU Connector Pin Description.....	7-12
Table Chapter 7 -17. POWER Connector Pin Description .....	7-13
Table Chapter 8 -1. Key Mnemonics .....	8-3
Table Chapter 8 -2. Setup Key Description .....	8-19
Table Chapter 8 -3. ACG Setup Menu .....	8-20
Table Chapter 8 -4. F3 Setup Menu.....	8-20

## Table of Contents

---

Table Chapter 8 -5. SYS Setup Menu.....	8-21
Table Chapter 8 -6. TRAN Setup Menu.....	8-23
Table Chapter 8 -7. EVENT Setup Menu.....	8-26
Table Chapter 8 -8. MEM Setup Menu.....	8-27
Table Chapter 8 -9. TCG Setup Menu.....	8-30
Table Chapter 8 -10. GRP Setup Menu.....	8-31
Table Chapter 8 -11. LOOP Setup Menu.....	8-34
Table Chapter 8 -12. RDY Setup Menu.....	8-35
Table Chapter 8 -13. TRKS Setup Menu.....	8-38
Table Chapter 8 -14. Error Register.....	8-47
Table Chapter 9 -1. Micro Lynx MIDI Setup Selections.....	9-11
Table Chapter 10 -1. TRAN Setup Options.....	10-5
Table Chapter 10 -2. Troubleshooting the M3 Card.....	10-7
Table Chapter 10 -3. ACG Card Sample Rate Ratios.....	10-14
Table Chapter 10 -4. ACG Setup Options.....	10-16
Table Chapter 10 -5. AES/EBU Connector Pin Description.....	10-19
Table Chapter 10 -6. Troubleshooting the ACG Card.....	10-20
Table Chapter 10 -7. F3 Setup Options.....	10-32
Table Appendix A-1. Frame Rate Formats.....	A-11
Table Appendix A-2. Setup Quick Reference Guide.....	A-23
Table Appendix A-3. Cable Reference Guide.....	A-25