

Service Bulletin

No. 95-004

TIMELINE VISTA, INC.

1755 LA COSTA MEADOWS DRIVE, SUITE B

SAN MARCOS, CA 92069

TEL. 760-761-4440

(FAX 760-761-4449)

SUPPORT@DIGAUDIO.COM

OPTIONAL

★ RECOMMENDED

★ MANDATORY

Lynx Studer A800 Cable Modification

DATE: 08/31/95

MODEL: Studer A800 Cable (TimeLine Part Number 71C025)

REVISION: All

SERIAL NO: Serial Numbers under 5078

SOFTWARE: N/A

REQUIRED TOOLS:

Soldering iron

REQUIRED PARTS:

(2) Hirose Male Pins, TimeLine Part Number 34W002

DESCRIPTION:

This modification is adding Mute Relay N/O to the Studer A800 cable.

PROCEDURE:

1. At the Lynx end of the cable (Connector A), add a pin to the Green (Red) pair. Install into Pin 46 of Connector A, as shown in schematic 70D038.
2. At the Lynx end of the cable (Connector A), add a ground wire and pin to the Black (BRN) pair. Install into Pin 48 of Connector A, as shown in schematic 70D038.